

AIR CONDITIONING	Maximum Care	Added Care Plus	Powertrain Care Plus
Air Conditioning Compressor Brackets			
Air Conditioning Hoses and Lines		<i>v</i>	V
Air Conditioning Housing, Levers			
and Linkage	v		
Air Conditioning/Heater Blower Motor	V	~	~
Air Conditioning Power Module	<ul> <li>✓</li> </ul>	~	~
Air/Recirculation Housing Door	V		
Blower Motor Resister	v		
Compressor Clutch	V	~	~
Clutch Cycling Switch	<ul> <li>✓</li> </ul>	~	~
Coil	~	~	~
Compressor	~	~	~
Condenser	V	~	~
Cool Air/Vent Control Cables	~		
Evaporator	V	~	~
Expansion Valve	V	~	~
Heater Core	~		
Heater Hoses, Lines and Tubes	~		
Heater Housing	~		
Heater Mode Control Cable	~		
Heater/Defroster Doors	~		
High Pressure Cut-Off Switch	V	~	~
Instrument Panel Control Assembly	V	<ul> <li>✓</li> </ul>	~
Low Pressure Cut-Off Switch	~	~	~
Module Blower Motor Control	V		
Motor/Actuator, Fresh Air/Recirculation	V		
Motor/Actuator, Mode Door	v		
Rear Air Conditioning Assembly	V		
Receiver-Drier	V	~	~
Seals and Gaskets	~	For Liste	ed Items
Temperature/Blend Air Door	V		
Thermistor Probe	<ul> <li>✓</li> </ul>		

🖾 BODY	Maximum Care	Added Care Plus	Powertrain Care Plus
Adjustable Cup Holder Mechanisms	V		
Center Console Door, Hinge and Lock	~		
Convertible Top Cylinders, Lines and Hinges	~		
Convertible Top Frame, Bows and Rails	~		
Door Check Straps	~		
Door Glass Tracks and Channels	~		
Door, Hood and Trunklid Hinges	<b>v</b>		
Hood Latch Release Cable	~		

D BODY	Maximum Care	Added Care Plus	Powertrain Care Plus
Hood Props	~		
Liftgate Props	~		
Spare Tire Hanger/Carrier	~		
Spare Tire Jack	~		
Washer Hoses and Nozzles	~		
Wiper Arm Linkage	<b>v</b>		

🛞 BRAKES	Maximum Care	Added Care Plus	Powertrain Care Plus
Adjustable Brake Pedal Assembly	~		
Assist Booster	~	~	
Brake Fluid Reservoir	~		
Brake Lines, Hoses and Fittings	~	~	
Brake System Hydraulic Assembly and Controller	V	~	
Disc Brake Calipers and Mounting Hardware	~	~	
Master Cylinder	~	~	
Parking Brake Cable	~		
Parking Brake Components	~		
Parking Brake Handle	~		
Parking Brake Cable Adjuster	~		
Proportioning Valve	~	~	
Pump Motor Assembly	~	~	
Seals and Gaskets	~	~	
Sensors and Relays	~	~	
Wheel Bearing Assemblies	~	~	
Wheel Cylinders	~	~	

□ → □ DRIVELINE/TRANSAXLE	Maximum Care	Added Care Plus	Powertrain Care Plus
Axle Housing and All Internal Parts	✓	~	~
Axle Shaft Assemblies	✓	~	~
Axle Shaft Bearings	~	~	~
Axle Shafts	~	~	
Constant Velocity Joints and Boots	<b>v</b>	~	~
Differential Carrier Assembly and All Internal Parts	~	~	~
Differential Cover	✓	~	~
Disconnect Housing Assembly	✓	~	~
Drive Shaft Assemblies	~	V	~
Drive Shaft Center Bearings	<b>v</b>	~	~
End Cover	~	~	~



DRIVELINE/TRANSAXLE	Maximum Care	Added Care Plus	Powertrain Care Plus
Front and Rear Axle Housing Assemblies and All Internal Parts	~	~	~
Front Wheel Bearings	<b>v</b>	~	~
Oil Pan	<b>v</b>	~	~
Output Ball Bearing	<b>v</b>	~	~
Output Flange	<b>v</b>	~	~
Overrunning Clutch	~	~	~
Pinion Spacer and Shim	<b>v</b>	~	~
Power Transfer Unit and All Internal Parts	~	~	~
PRNDL Position Switch	~	~	~
Rear Axle Housing and All Internal Parts	~	~	~
Rear Driveline Module	~	~	~
Seals and Gaskets	~	Listed compo	nents ONLY
Torque Converter	~	~	~
Torque Tube	~	~	~
Transaxle Case and All Internal Parts	~	~	~
Transaxle Electronic Controller	~	~	~
Transaxle Solenoid Assembly	~	~	~
Transaxle Speed Sensor	~	~	~
Transfer Case/Power Transfer Unit and All Internal Parts	v	V	~
Universal Joints and Yokes	~	~	~
Viscous Coupler	<b>v</b>	~	~

© ELECTRICAL	Maximum Care	Added Care Plus	Powertrain Care Plus
Air Bag and Side Air Bag Control Modules	~		
All Relays	~		
All Wiring Harnesses	~	<ul> <li>✓</li> </ul>	
Automatic Headlamp Sensor	~		
Auxiliary 12-Volt Power Outlet	~		
Auxiliary 115-Volt Power Outlet and A/C Inverter	~		
Battery Heater	~		
Battery Hold Down	~		
Body Computer	~	~	
Body Control Module	~	~	
Charging Area	~		
Cigar Lighter Assembly	~		
Coil Pack Assembly	~	<ul> <li>✓</li> </ul>	
Compass Sensor Module	~		
Daytime Running Lights Module	~		
Distributor	~	<b>v</b>	

≥ Electrical	Maximum Care	Added Care Plus	Powertrain Care Plus
Electronic Fuel Injection System (Excluding Clogged Injectors)	~	~	
Electronic Stability Program	~		
Engine Control Module	~	~	
Factory Installed Radios and Speakers	~	~	
Fuse/Relay Block	<b>v</b>		
Garage Door Opener Transmitter	~		
Generator/Alternator	~	~	
Generator/Alternator Pulley, Bracket and Adaptor	V		
Glow Plugs	~		
Hands Free Cellular Telematics	~		
Heated Seat Control Module	~		
Heated Seat Element Pads and Module	v		
Hill Descent Control	<b>v</b>		
Hill Start Assist	<b>v</b>		
Horn and Horn Pad	v	~	
Ignition Coil	v	~	
Low Tire Pressure Sensors	v		
Manually Operated Electrical Switches	~	~	
Memory Seat Control Module	~		
Mopar <sup>®</sup> Accessories (Authorized Chrysler, Dodge, Jeep <sub>8</sub> , Ram, FIAT <sub>8</sub> or Alfa Romeo Facility Installations Only)	V		
Occupant Classification System Module	<b>v</b>		
Oil Pressure Sending Unit/Switch	<b>v</b>	~	
Park Neutral Position Switch	~	~	
ParkSense® Rear Back Up Warning System	<b>v</b>		
ParkSense® Rear Back Up Monitor System	v		
Power Door/Liftgate Motor	<b>v</b>		
Power Folding Seat Motors	v		
Power Sliding Door/Liftgate Module	~		
Powertrain Control Module	~	~	
Quarter Vent Window Motor	~	~	
Rear Seat Video Systems	~		
Rear Window Wiper Motor	~	~	
Remote Start Systems (OEM)	~		
Satellite Radio System	~		
Satellite Television System	~		
Security Alarm System	~		
Sensor, Charge/Air Inlet Temperature	~		
Sliding Door Alert Warning System	~		
Starter Motor and Solenoid	~	<ul> <li>✓</li> </ul>	
Temperature Sending Unit/Switch	~	~	



© Electrical	Maximum Care	Added Care Plus	Powertrain Care Plus
Tire Pressure Monitor/Warning System	~		
Traction Control System	v		
Trailer Sway Damping System	<b>v</b>		
Transmission Control Module	<b>v</b>	~	
Uconnect® Hands-Free Communication System	<b>v</b>		
USB Port	v		
Voltage Regulator	<b>v</b>	~	
Washer Fluid Reservoir and Pump/Motor	v		
Windshield Wiper Motor	<b>v</b>	~	
Wiper Control Module	<b>v</b>	~	

ố갈 Engine	Maximum Care	Added Care Plus	Powertrain Care Plus
Air Cleaner Assembly (Excluding Element)	~		
Core Plugs	~	~	~
Cylinder Block and All Internal Parts	V	<ul> <li>✓</li> </ul>	~
Cylinder Head Assemblies	~	~	~
Engine Supports/Mounts	<b>v</b>		
Flex Plate/Drive Plate	V	~	
Flywheel with Starter Ring Gear	<ul> <li>✓</li> </ul>	<ul> <li>✓</li> </ul>	~
Fuel Injection Pump (Diesel Engines Only)	~	~	~
Fuel Injectors (Excluding Clogged Injectors)	<ul> <li>✓</li> </ul>	~	~
Harmonic Balancer	~	~	~
Hose, Secondary Air Supply	~		
Hoses and Clamps	~		
Idler Pulley	~		
Intake and Exhaust Manifolds	~	~	~
Oil Filter Adapter Housing	~	<ul> <li>✓</li> </ul>	~
Oil Pan	✓	<ul> <li>✓</li> </ul>	~
Oil Pump	<ul> <li></li> </ul>	~	~
Pulleys and Sprockets	~		
Pump, Air	V		
Pump, Leak Detection and Hoses/Lines	V		
Seals and Gaskets	~	Listed compo	nents ONLY
Serpentine Belt Tensioner	V	~	~
Supercharger	~	~	~
Timing Case, Chain, Gears, Belt and Sprockets	~	~	~
Turbocharger Housing and All Internal Parts	~	~	~
Turbocharger Waste Gate Actuator	~	~	~
Valve Covers	~	~	~
Valve, Exhaust Gas Recirculation Control	~		
Water Pump and Housing	~	~	~

© Electrical	Maximum Care	Added Care Plus	Powertrain Care Plus
Accelerator Pedal and Linkage	~		
Coolant Recovery Bottle and Hose	~		
Coolant Temperature Switch	~	~	
Cooling Fan, Clutch and Motor	~	~	
Cooling System Hoses and Clamps	<b>v</b>		
Engine Oil Cooler, Hoses and Lines	<b>v</b>		
Evaporation Canister and Hoses	<b>v</b>		
Fuel Pump	<b>v</b>	<b>v</b>	
Fuel Tank and Lines	~	~	
Fuel Tank Filler Cap and Door	~		
Fuel Tank Sending Unit	~	~	
Radiator	~	~	
Radiator Cap	~		
Radiator Fan Shroud	~		
Radiator Hoses, Upper and Lower	~		
Seals and Gaskets	v	<b>v</b>	
Serpentine Belt Tensioner	<b>v</b>	<b>v</b>	
Speed Control Vacuum Reservoir	~		
Speed Control/Throttle Body Cables and Hoses	v		
Thermostat and Gasket/O-Ring	~		
Turbocharger Coolant Tube/Line	~		
Water Pump and Housing	~	~	
Water Pump Transfer Tube and O-Rings	~		

INSTRUMENT PANEL	Maximum Care	Added Care Plus	Powertrain Care Plus
Amp/Voltmeter Gauge	~	~	
Clock	~		
Electronic Instrument Cluster	~	~	
Fuel Gauge	~	<b>v</b>	
Oil Pressure Gauge	~	v	
Speedometer	~	v	
Tachometer	~	~	
Temperature Gauge	~	~	
Turbo Gauge	~	~	

🚔 LUXURY GROUP	Maximum Care	Added Care Plus	Powertrain Care Plus
Convertible Top Motor	<b>v</b>	~	
Cruise Control Servo	✓	~	
Electric Mirror Motor and Controls	~	<ul> <li></li> </ul>	



E LUXURY GROUP	Maximum Care	Added Care Plus	Powertrain Care Plus
Electronic Vehicle Information Center	~		
Headlight Door Motor	~	~	
Heated Seat Elements	~		
Keyless Entry Receiver/Module	~	~	
Message Center	~	~	
Overhead Electronic Compass/Temperature	~	~	
Overhead Electronic Vehicle Information Center	V	~	
Power Sunroof Motor	~	~	
Trip Computer	~	~	
Key Fob	~	~	~

MANUAL INTERIOR MECHANISMS	Maximum Care	Added Care Plus	Powertrain Care Plus
Seat Base Riser	<b>v</b>		
Seat Belt Shoulder Height Adjuster/Knob	<b>v</b>		
Seat Lumbar Adjuster	v		
Seat Manual Height Adjuster	✓		
Seat Manual Track Adjuster	✓		
Seat Recliner Assembly	✓		
Stow 'n Go® Seat Mechanisms	~		

OWER GROUP	Maximum Care	Added Care Plus	Powertrain Care Plus
Decklid Release Cable	~		
Power Antenna	~	~	
Power Door Locks and Linkage (Excluding Latch Assembly)	~	V	
Power Seat Motors	~	~	
Power Sliding Door Motors	~		
Power Window Flex Track	~	~	
Power Window Motors	~	~	
Rear Window Defroster	<ul> <li>✓</li> </ul>	~	

SAFETY & SECURITY	Maximum Care	Added Care Plus	Powertrain Care Plus
Air Bags	~		
Air Bag Clock Spring	~		
Air Bag Sensors	~		
Door Lock Cylinders	V		
Hazard Warning Lamps and Relays	<b>v</b>		

🚊 SAFETY & SECURITY	Maximum Care	Added Care Plus	Powertrain Care Plus
Ignition Switch Lock Cylinder	~		
Seat Belt Assemblies	~		
Trunk Emergency Release Cable & Mechanism	~		

💮 STEERING	Maximum Care	Added Care Plus	Powertrain Care Plus
Power Steering Cooler and Tubes	~		
Power Steering Gear	~	~	~
Power Steering Pump	~	~	~
Power Steering Pump Bracket and Pulley	~		
Power Steering Pump Reservoir and Cap	~		
Rack and Pinion Assembly	~	~	~
Seals and Gaskets	~		
Seals and Gaskets for Listed Components	~	~	~
Steering Column Assembly	~		
Steering Damper	~		
Steering Gear Housing and All Internal Parts	~	~	~
Steering Shaft Lower Coupling	~	~	~
Steering Wheel Tilt Lever	~		

الله عنه العام ا معام العام العام مام العام العامم العام العام العام العام	Maximum Care	Added Care Plus	Powertrain Care Plus
		I	1
Auxiliary Springs	~		
Axle Trac Bar	~		
Bushing Stabilizer Bar	~		
Control Arm Bushings	~		
Control Arms	~		
Cushion Stabilizer Bar	~		
Front Axle Crossmember	~		
Front Axle Vent and Hose Assembly	~		
Front Control Arm Bushings	~	~	
Front Control Arms	~	~	
Front Spring Bushing	~		
Front Spring Hanger	~		
Front Spring Interliner	~		
Front Spring Seat	~		
Front Spring Shackle	~		
Front Stabilizer/Sway Bar Link	~		
Front Upper and Lower Ball Joints	~	~	
Front Upper and Lower Control Arms		~	
Lateral Link Arm	~		
Link Stabilizer Bar	~		



الله المعالم المحالي محالي	Maximum Care	Added Care Plus	Powertrain Care Plus
Rear Auxiliary Springs	· ·	~	
Rear Axle Trac Bar	~	~	
Rear Camber, Spring, Toe, Links	~		
Rear Coil Springs	~	~	
Rear Lateral Link Arm	~	~	
Rear Leaf Springs	~	~	
Rear Shock Mount Plate	~	~	
Rear Springs	~	~	
Rear Spring Bushing	~	~	
Rear Spring Hanger	~	~	
Rear Spring Interliner	~	~	
Rear Spring Shackle	~	~	
Rear Stabilizer/Sway Bar	~	~	
Rear Stabilizer/Sway Bar Bushing	~	~	
Rear Stabilizer/Sway Bar Link	~	~	
Rear Trailing Arm Assembly	~	~	
Shock Absorbers	~	~	
Shock Mount Plate	~		
Stabilizer/Sway Bar	~	Listed components ONLY	
Strut Assemblies	~	Listed compo	nents ONLY
Suspension Knuckles	~		
U-Bolt Rear Spring	~	~	

() TRANSMISSION (AUTOMATIC)	Maximum Care	Added Care Plus	Powertrain Care Plus
Automatic Transmission Case and All Internal Parts	~	~	~
Drive/Flex Plate	<ul> <li>✓</li> </ul>	~	~
Seals and Gaskets	~	Listed components ONLY	
Torque Converter	~	~	~
Transmission Control Module	~	~	~
Transmission Cooler, Hoses, Lines	~		
Transmission Oil Pan	~	~	~
Transmission Range Switch	~	~	~
Transmission Shifter Interlock Solenoid	~	~	v

() TRANSMISSION (CVT)	Maximum Care	Added Care Plus	Powertrain Care Plus
Continuously Variable Transmission and All Internal Parts	~	~	~
CVT Belt	~	~	~
CVT Neutral, Safety, Backup Switch	~	~	~
Forward and Reverse Clutch	~	~	~

()] TRANSMISSION (CVT)	Maximum Care	Added Care Plus	Powertrain Care Plus
Input Speed Sensor	<ul> <li>✓</li> </ul>	V	~
Output Speed Sensor	~	~	~
Planetary Gearset	~	~	~
Primary Variator	~	~	~
Seals and Gaskets		Listed components ONLY	
Secondary Variator	~	~	~

() TRANSMISSION (CVT)	Maximum Care	Added Care Plus	Powertrain Care Plus
Bell Housing	~	~	~
Clutch Hydraulic Fluid Reservoir Hose	~		
Clutch Hydraulic Fluid Reservoir	<ul> <li>✓</li> </ul>		
Clutch Hydraulic Tube	~		
Clutch Master Cylinder	~		
Clutch Release Cable	~		
Clutch Release Fork	<ul> <li>✓</li> </ul>		
Clutch Slave Cylinder	~		
Gear Shift Lever Assembly	~		
Gear Shift Linkage	~		
Manual Transmission Case and All Internal Parts	~		
Seals and Gaskets	~	Listed components ONLY	
Shifter Lock Cable	~		

Choose one of our factory backed coverage options.

### **POWERTRAIN CARE PLUS:**

This plan extends your vehicle coverage on over 400 major components. A good solution when it comes to protecting your vehicle.

### **ADDED CARE PLUS:**

This plan extends your vehicle coverage on over 850 components. A better solution when it comes to protecting your vehicle.

### **MAXIMUM CARE:**

This plan extends coverage on over 5000 components. It is by far the best coverage.

The above are the most common parts that are covered under each plan. Please refer to actual plan for parts and services that are not covered and other exclusion that may apply.

©2020 FCA US LLC. All Rights Reserved. Chrysler, Dodge, Jeep, Ram, Mopar and SRT are registered trademarks of FCA US LLC. FIAT is a registered trademark of FCA Group Marketing S.p.A., used under license by FCA US LLC. In Florida, Mopar Vehicle Protection Extended is a service contract from FCA Service Contracts LLC (License #65505). In Texas, Mopar Vehicle Protection Extended is a service contract from FCA Service Contracts LLC (License #SCP-584).